


# Magnetic control of laser ablation plasma for high-flux ion injectors


Shunsuke Ikeda, Mitsuo Nakajima, Jun Hasegawa,  
Tohru Kawamura and Kazuhiko Horioka

*Department of Energy Sciences, Tokyo Institute of  
Technology, Nagatsuta 4259, Midori-ku, Yokohama,  
226-8502, Japan*

Magnetically controlled laser ablation plasma can be applied for high-flux ion injector



High drift velocity  $u$   
Low ion temperature  $T$



Large supply current  $I_d$   
Low emittance  $\varepsilon$

## Advantages of magnetically controlled ablation plasma

- Laser ablation plasma has high drift velocity and low temperature after adiabatic expansion.  
→ high-flux and low-emittance ion injector.  
 $(I_d = aZe nu$  and  $\varepsilon = a(kT/mc^2)^{1/2})$
- To supply directional and high flux plasma to the extractor, we introduced Magnetic field guiding for expanding plume.


It was found that **weak (0.1 T)** magnetic field (plasma pressure  $\sim 10\text{MPa} \gg$  magnetic pressure  $\sim 10\text{kPa}$ ) can modify plasma flux of ions.

Longitudinal magnetic field was applied to the ablation plasma

Movable aperture ( $\Phi$  1 mm)

Nd:YAG Laser (532 nm, 10 ns)

Cu target



50 mm

Pulsed coil (1 ms, 0~0.2 T)


6 mm

$L=170$  mm

x

0



Biased plate



# The plasma ion flux on the axis as a function of the magnetic flux density and laser intensity

(a)  $E_L = 3.2 \times 10^8 \text{ W/cm}^2$


(b)  $E_L = 9.5 \times 10^8 \text{ W/cm}^2$



- Additional fast peak appeared with weak magnetic field.
- Arrival time of fast peak increased with magnetic field.
- Fast peak increased (5-7 times), then decreased slowly and became wider with increasing magnetic field.
- Slow peak appeared and increased with magnetic field.



# The plasma ion flux as a function of the transverse distance $r$



$$B = 0.066 \text{ T}$$

$$E_L = 3.2 \times 10^8 \text{ W/cm}^2$$


$$r = 0-17 \text{ mm } (0-5.7^\circ)$$

- Fast peak appeared in magnetic field had a very narrow angular distribution, corresponding  $\cos^{300}\theta$
- At  $x = 17$  mm, TOF spectra were similar to those without magnetic fields.

# Ion energy analyzer


The distance  $L$  from the target to the electron multiplier is 610 mm and 850 mm

Movable ion flux detector




200 mm

350 mm



# Typical signal of ion energy analyzer




$$\frac{M}{z} = \frac{t^2 e U}{L^2 \ln(R_1/R_2)}$$





identify the ion  
and  
obtain the ion flux spectra



# Result of ion energy analysis at $E_L = 3.2 \times 10^8 \text{ W/cm}^2$ , $B = 0.066 \text{ T}$ , $L = 850 \text{ mm}$




- The additional fast peak was composed of highly charged ions.
- Higher charged ions were faster and more increased.





Time (μs)

# Result of ion energy analysis at $E_L = 9.5 \times 10^8 \text{ W/cm}^2$ , $B = 0.09 \text{ T}$ , $L = 610 \text{ mm}$



- The highly charged ions increased too, but more slightly.
- Singly-charged ion more increased (1.1 times  $\rightarrow$  2 times).



## Summary


We investigated the effect of the magnetic field on the laser ablation plasma and observed the following effects.

- Additional fast peak appeared with weak magnetic field.
- The fast peak increased drastically, then decreased slowly and became wider with increasing magnetic field.
- The fast peak had a very narrow angular distribution
- The fast peak was composed of highly charged ions.
- Slow peak appeared and increased with the magnetic field.

## Discussion I : formation of electric field

Additional fast peak composed of highly charged ions and its very sharp angular distribution indicate that

- presence of electric field that accelerate the ions
- the electric field become directional by the longitudinal magnetic field.



## Discussion 2 : increase of recombination


Increase of slow peak and the spread of the fast peak indicate that

- the magnetic field increases the collision frequency and sets on the recombination.



## Discussion 2 : increase of recombination

Plasma plume



# Conclusion


Followings were indicated

By the axial magnetic field;

- Directional electric field is formed.
- Recombination increases.

# The plasma flux as a function of the distance at $E_L = 9.5 \times 10^8 \text{ W/cm}^2$


$z = 170 \text{ mm}$



$6.0 \text{ cm}/\mu\text{s}$   
(1.2 keV)

$2.9 \text{ cm}/\mu\text{s}$   
(300 eV)


$z = 280 \text{ mm}$







$6.0 \text{ cm}/\mu\text{s}$

$3.0 \text{ cm}/\mu\text{s}$

# The transverse distribution at $z = 170$ mm, $E_L = 3.2 \times 10^8$ W/cm<sup>2</sup>




# Reproducibility of the signal of the biased plate (at $z = 170$ mm, $E_L = 9.5 \times 10^8$ W/cm<sup>2</sup>)








# Dependency of the peak flux on bias voltage



# The magnetic configuration estimated by numerical calculation



# Electrostatic Energy Analyzer

