


Update on the MDPCT1 coil #5 X-ray test

Igor Novitski
Fermilab

September 15, 2021


Outer Coils #4/5 – Inner Layer View, RE after Test 2



- Outer coils have degradation
- Can be used in hybrid configuration

Coil 4

Coil 5




CERN 11T coil pictures

Global High Energy X-ray Computed Tomography

6 MeV LINAC tomography - TEC-Eurolab Modena /IT

Resolution: 120 μm
Spot size: 2 mm
Energy: 6 MeV



X-Ray Source

Detector

Scan Volume, maximum
Focus-Detector-Distance
Sample Weight
System Dimensions
System Weight
Manipulation

3 / 6 / 9 [MeV]

Flat Panel Detector
3.000 x 3.000 px, 140 μm

\varnothing 700 x 1000 H [mm]

4000 [mm]

200 [kg]

L 5.900 x B 1.500 x H 2.900 [mm]


17 [t]

granite based, 6 / 7 axes,

3. Coil GEC02 – Events




Event 1 – first end cable
in inner layer,

Misaligned strands
(pop-in / pop-out)



Event 2 – vicinity of fourth
spacer in inner layer,

Bulged cable








2021.04.15

S. Sgobba et al., Advances in imaging and diagnostics

21

3. Local CT - Coil GEC02 – Event 2



2021.04.15

S. Sgobba et al., Advances in imaging and diagnostics


23



2021.04.15

S. Sgobba et al., Advances in imaging and diagnostics

17




2021.04.15

S. Sgobba et al., Advances in imaging and diagnostics

22

North Star 3D CT imaging at Alloyweld near O'Hare



System Capabilities

Geometric Magnification	>3000x
Overall Maximum System Resolution	~500 nm

X-Ray Source

Voltage Range	10 kV to 450 kV
Minimum Focal Spot Size	~500 nm
X-Ray Tube Types	Nano-focus Micro-focus Mini-focus
Dual Tube Configuration	Optional

X-Ray Detector

Detector Types	Flat Panel (DDA) Linear Diode Array (LDA)
Grade Options	Standard Premium ASTM
Maximum Detector Size	16 in x 16 in [40 cm x 40 cm]
Dual Detector Configuration	Optional

Virtual Detector Dimensions Using a 16 in x 16 in [41 cm x 41 cm] Detector

	Standard	w/VorteX	w/MosaiX
Diameter	~16 in [40 cm]	~16 in [41 cm]	~39 in [100 cm]
Height	~16 in [40 cm]	~57 in [145 cm]	~57 in [145 cm]

Exact specifications vary depending on tube, detector, and other optional configurations.


Manipulator

Maximum Sample Weight	500 lb [227 kg]
Axis Travel	Vertical: 48 in [121 cm] Horizontal: 32 in [81 cm] Tilt: +20° / -20° Rotation: 360° Continuous
Nominal Part Envelope	Diameter: 32 in [81 cm] Height: 48 in [121 cm]


Cabinet

	240 kV	450 kV
Width	115 in [292 cm]	115 in [292 cm]
Depth	80 in [203 cm]	80 in [203 cm]
Height	98 in [249 cm]	928 in [249 cm]
Weight	14800 lb [6170 kg]	29000 lb [13200 kg]



All cabinets are steel/lead/steel construction that meet or exceed 21 CFR 1020.40 and EN 61010-2-091 2012.



2D picture at 300 kV -10 mA- 2min 30 sec



Outer Coil #5 - Inner Layer View, RE



450 kV CT at Minnesota

From: Justin Olsen <justin@avoniximaging.com>
Sent: Friday, September 03, 2021 5:29 PM
To: Igor Novitski <novitski@fnal.gov>
Cc: Alexander Zlobin <zlobin@fnal.gov>
Subject: Re: Project Discussion

Igor,

Thanks for reaching back with all the information. I would like to set up some time to talk with you further about your project. The system we would likely need to use is our M2 with a 450kV microfocus source.

Would you have some time next week to discuss further?

Regards,



Justin Olsen | Business Development Representative
– Inspection Services

office: 763.447.4187 | mobile: 763.213.7079

e-mail: justin@avoniximaging.com

6705 Wedgwood CT N | Maple Grove, MN 55311



After meeting note:

The new machine set up with a manipulator to hold the whole coil
 will be available in November-December
 with capability to CT a volume 180 mm^3 at – 450 kV
 \$1200 per scan + soft
 Time - 2 weeks

The company with its headquarter in Hattingen, Germany and US office in Las Vegas NV, focuses on standard as well as customized industrial CT systems by using a wide range of vendor independent X-ray sources and digital imaging detectors.


diondo d₇ High-Performance Linear Accelerator CT System for Analyzing & Testing of High-Density Components

Applications

The range of applications includes everything from complex measurements of tiny components up to classical non-destructive testing of voluminous objects.

The diondo d₇ is used for measuring and analyzing very diverse test parts and materials such as:

- Electric mobility
[rotors, strators,...]
- Automotive
[engine blocks, cylinder heads,...]
- Energy
[turbine blades,...]
- Air & Aerospace
[power unit components,...]
- Mechanical engineering
[high-alloy steels, cast-iron components, ...]



CT System Specifications

X-Ray Source.....3 / 6 / 9 [MeV]

Detector:

Flat Panel Detector.....3.000 x 3.000 px, 140 [µm]

Line Detector.....px, 200 [µm]

Scan Volume, maximum
Ø 700 x 1000 H [mm] with Flat Panel Detector
Ø 1000 x 1000 H [mm] with LDA

Focus-Detector-Distance..... Variable to 4000 [mm]

Sample Weight.....200
[kg]

System Dimensions.....L 5.900 x B 1.500 x H 2.900 [mm]

System Weight17 [t]

diControl Features


DR-Function, di Scatter, Scan Enhancement, Multiline CT, Daily Check, Health Monitor, Helix CT, Batch Mode, Offset CT, Limited Angle CT

Manipulation..... granite based, 6 / 7 axes

Optional customized features are available upon request.

diondo d₇

Comparison between 450 kV and 6 MeV



450 kV cone beam CT with flat panel detector

Test steel test specimen

- Diameter
95 mm
- Investigation time
1 hour


6 MeV cone beam CT with flat panel detector

Test steel test specimen

- Diameter
95 mm
- Investigation time
1 hour

diondo d₇

Comparison between 450 kV and 6 MeV



Fan beam CT of an aluminium V8 cylinder head, Diameter 450 mm

Comparison between 450 kV and 6 MeV

450 kV

Due to the immense material thickness a reliable defect detection is not possible

6 MeV

Thanks to the high penetration power not only the measurement time is drastically reduced, but also the test result allows a reliable defect analysis. Additionally, the excellent contrast values and clear object outlines allow measurement analyses.




diondo Inc. Business Office

1614 Navajo Point Place
Henderson, NV 89074
Phone: 702-822-0585

diondo GmbH

Ruhrallee 14
45525 Hattingen, Germany
Phone: +49 2324 393 19-0



<https://www.diondoinc.com/>

From: Greg Budner <Greg.Budner@diondo.com>
Sent: Thursday, September 16, 2021 9:26 AM
To: Igor Novitski <novitski@fnal.gov>
Cc: Benjamin Zengerling <Benjamin.Zengerling@diondo.com>
Subject: RE: 6 MeV imaging

Dear Igor:

We have reviewed your pictures and as discussed earlier we are familiar with this type of part. Our scanning fee is \$2900 per scanning area view. There will be a shipping charge so we will need to know the weight and dimensions and we will need to make a reusable shipping container. From our dock, it is about 5 days to turn around the part.

Best regards,
Greg